






















Designed by


*Leonhard Pfeifer*






<p>A1</p>  <p>x53</p> <p>Ø8x35</p>		<p>A12</p>  <p>x24</p> <p>Ø3,5x16</p>
<p>A2</p>  <p>x38</p> <p>Ø7x24</p>		<p>A13</p>  <p>x1</p> <p>4mm</p>
<p>A3</p>  <p>x38</p>		<p>A14</p>  <p>x3</p> <p>Ø5</p>
<p>A4</p>  <p>x5</p> <p>(Ø3,5x35)</p>	<p>A8</p>  <p>x8</p>	<p>A15</p>  <p>x5</p> <p>20mm</p>
<p>A5</p>  <p>x12</p> <p>Ø6,3x11</p>	<p>A9</p>  <p>x4/x1</p> <p>M6x30/M6x40</p>	<p>A16</p>  <p>x3</p> <p>(Ø3x20)</p>
<p>A6</p>  <p>x22</p> <p>Ø17</p>	<p>A10</p>  <p>x5</p> <p>M6/10x20</p>	<p>A17</p>  <p>x6</p> <p>(Ø3x20)</p>
<p>A7</p>  <p>x3</p> <p>310mm</p>	<p>A11</p>  <p>x4</p> <p>90x40x1,5</p>	<p>A18</p>  <p>x2</p> <p>Ø8</p>


step 1




step 2




step 3




step 4




step 5




step 6




## step 7




## step 8





step 9



step 10 x3




step 11



#### Height adjustment

It's possible to make height adjustments of up to +2.5 mm. This tool-free feature produces uniform gap alignment.



#### Lift-off stop

The lift-off stop prevents drawers and pull-outs from accidentally lifting off the runner. If required, the lift-off stop can be released by pulling a lever.

step 12

